

# **Installation Guide for Millennium Corner & Wall Face Baths**

## **PRE-INSTALLATION CHECKS.**

UNPACK & CHECK THE ITEM IS CORRECT & NO DAMAGE HAS OCCURRED DURING TRANSIT.  
**IF THERE ARE ANY VISIBLE DEFECTS DO NOT PROCEED WITH THE INSTALLATION & PLEASE CONTACT THE PLACE OF PURCHASE IMMEDIATELY.**

**ANY CLAIMS FOR DAMAGE WILL NOT BE ACCEPTED AFTER INSTALLATION.**

PROTECT YOUR BATH BEFORE & DURING INSTALLATION; SCRATCHES & OR CRACKS & OR SURFACE DAMAGE SUSTAINED DURING OR AFTER THE INSTALLATION ARE NOT COVERED BY WARRANTY. INSTALLATION MUST BE IN ACCORDANCE WITH BUILDING REGULATIONS & LOCAL AUTHORITY REQUIREMENTS.

1. Remove your Millennium wall face or corner bath from the box. Check for damage and ensure your bath does not come into contact with any rough surfaces which may scratch your bath. Place your bath on cardboard or carpet during installation process. Place the bath in the correct position for installation.
2. Adjust the levelling feet until the bath base is 3-4mm above the finished floor. Turn the adjustable legs and level accordingly. Ensure there is 3-4mm of space between the bottom of the bath shell and the floor. Installing directly on the floor will place pressure on the outside wall of the bath and will potentially crack the bath. Ensure the bath is level so all water can drain to the waste outlet.
3. Carefully tilt the bath on its side and connect it to the drain outlet. We recommend using a Flexible Connector. Ensure the Flexible Connector is cut to the correct length for easier installation and to prevent drainage issues
4. Before finishing, water test for leaks and correct drainage: Fill the bath with water and check the water flows easily to the waste outlet. A small amount of residual water may be present due to surface tension.
5. Move bath partially away from the wall and apply silicon to the waste end and side walls for corner baths/side wall only for wall face baths that push up against the wall.
6. Finalise installation by applying a bead of silicone around the top of the bath outline where it meets the wall. Allow 24 hours for silicone to set prior to using the bath.

Millennium uses high quality sanitary grade acrylic which is resistant to most things it may come into contact with. However naked flames, cigarettes or strong chemicals should be avoided and removed immediately. To preserve the high gloss acrylic surface Millennium recommends the following: •

When filling the bath start with cold water to allow the bath to gradually adapt to the temperature.

- After using your bath clean with a soft cloth and warm soapy water to clean any oils or soap residues, to prevent tide marks & preserve the polished surface.
- We recommend cleaning using warm soapy water and only using mild liquid detergents. Do not use powders, pastes, creams, chemicals, window cleaning sprays, chemicals or abrasive cleaners.
- Cream-type cleaners may be used sparingly and only to remove stubborn marks. Scratches can be removed with a fine polish like 'Brasso.